



Drake Manual List

[|A|](#)[|B|](#)[|C|](#)[|D|](#)[|E|](#)[|F|](#)[|G|](#)[|H|](#)[|I|](#)[|J|](#)[|K|](#)[|L|](#)[|M|](#)[|N|](#)[|O|](#)[|P|](#)[|Q|](#)[|R|](#)[|S|](#)[|T|](#)[|U|](#)[|V|](#)[|W|](#)

[|1|](#)[|2|](#)[|3|](#)[|4|](#)[|5|](#)[|6|](#)[|7|](#)[|8|](#)[|9|](#)



Model	Part #	Description
1-A		Sideband Receiver
1525-EM	1525	Pushbutton Encoding Microphone for UV-3 and TR-33C
1548	1548	R7/TR7 Interface Cable Kit
2-A		HF ham band receiver
2-AC		100 Kc. Calibrator
2-AQ		Speaker / Q-Multiplier
2-AS		Speaker FOR 2-B
2-B		HF Receiver
2-B		HF Receiver
		Modifying the 2-A & 2-B to receive 1.8 to 2.0 KC
2-BQ		Speaker / Q-Multiplier
2-C		HF hamband receiver
2-CQ		Speaker / Q-Multiplier



Model	Part #	Description
2-CS		Speaker FOR 2-C 19
2-LF		Low Frequency Adapter for 2-B
2-NB		Noise Blanker for 2-C
2-NT		HF CW Transmitter
34-PNB		Noise Blanker
4-LF		Low Frequency Adapter for 4 Line
4-NB	1217	Noise Blanker for R-4C
5-NB	1227	Noise Blanker for SPR-4
		From SPR-4 Manual
7072	7072	Handheld Microphone for T-4X
7073	7073	Mobile Microphone for TR-7
7075	7075	Desk Microphone for T-4X
7077	7077	Microphone



Model	Part #	Description
		Modifications for 7077 mic on TR7
9-NB		Noise Blanker
AA-22		2 Mtr. Amplifier
AC-10	1321	AC Power Supply
AC-3		TR-3 AC Power Supply
AC-4	1501	4 Line Power Supply
		AC-4 Spare Parts List
AL-4	1235	Loop Antenna for SPR-4, SW-4
AN-5	1237	Antenna Kit for SPR-4
AUX7	1536	Auxiliary Program Board for TR7
B-1000	1510	4:1 Balun for MN-4C/MN-7/MN-2700
C-4		Station Control
		Temporary Supplement to C-4 Manual



Model	Part #	Description
CA-1		4 LINE STACKING CABINET 70
CC-1		Converter Console Case for SC-2, SC-6, CPS-1
		Composite Spares list for SC2/6, TC2/6, SCC-1, CPS-1 & CC-1
CPS-1		Power Supply for SC-2 &6
CS-7	1533	Coax Switch
	1534	Control Console for CS7
	1535	Remote Switch for CS7
DC-3		TR-3 12 VDC Power Supply
DC-4	1505	DC Power Supply
DC-PC	1229	DC Power Cord for SPR-4
DL-300	1550	300 Watt Dry Dummy Load
DL-1000	1551	1000 Watt Dry Dummy Load
DR7	1530	General Coverage/Digital Readout Board



Model	Part #	Description
DSR-1		Digital HF Receiver
DSR-2	1242	Digital HF Receiver
FA-7	1529	Fan for TR-7 Transceiver
FF-1	1315	Fixed Frequency Control for TR-4
FL250	7011	CW Filter, 250 Hz for R-4C Receiver
FL500	7013	CW Filter, 500 Hz for R-4C Receiver
FL1500	7015	SSB/RTTY Filter, 1.5 kHz for R-4C Receiver
FL4000	7017	AM Filter, 4.0 kHz for R-4C Receiver
FL6000	7019	AM Filter, 6.0 kHz for R-4C Receiver
FS-4	1520	Frequency Synthesizer
		FS-4 Spare Parts List
HS-1	7078	Headphone
L-4		Linear Amplifier



Model	Part #	Description
L-4B	1519	2 KW HF Amplifier
		Tuning the L4B to meet FCC requirements
		L-4B Spare Parts List
L7	1528	Linear Amplifier
LA-7		Audio Amplifier
LN-4		AC Line Filter
LN-5		AC Line Filter
LP-100/1000-TV		LP Filter
MC-4		Mobile Wattmeter / Speaker
ML-2		2 Mtr. Transceiver
Miscellaneous		Manuals not classified elsewhere
		Drake TVI letter
		Drake Crystal Ordering Form



Model	Part #	Description
		Magnum 6 RF Speech Processor
		Torrestronics Universal Frequency Readout, TK-1
		TK-1 Mating Instructions
		e-tek FR-4 Frequency Readout for R-4
		e-tek FR-4tr Update
MMK-3		Mobile Mounting Kit
MMK-7	1335	Mobile Mounting Kit for TR-7 Transceiver
MN-2000	1509	2 KW HF Tuner
		Spare Parts List
MN-2000		2 KW HF Tuner
MN-2700	1539	Matching Network, 160-10 meters, 2kW
MN-4	1507	300 WATT HF Tuner
		Spare Parts List



Model	Part #	Description
MN-4C		Matching Network
MN-75		Matching Network
MN-7	1538	Matching Network, 250 Watt 160-10 Meter, with RF Wattmeter
MNK-22		Mobile Mount for TR-22
MS-4	1511	Speaker and Cabinet for 4 Line
MS-7	1531	Matching Speaker for TR-7 Transceiver
MSR-1		Marine HF Receiver
MSR-2		Marine HF Receiver
NB-6		Noise Blanker for TR-6
NB-7	1537	Noise Blanker for TR-7 Transceiver
NB-7A	1532	Noise Blanker for R-7 Receiver
P75		P75 Phone Patch
PS-3	1504	120/240V AC Power Supply for UV-3



Model	Part #	Description
PS-7	1502	120/240V AC Power Supply for TR-7 Transceiver
		PS-7 Shutdown and the PS-75
PS-75		120/240V AC Power Supply for TR-7 Transceiver
Q-Xer		Q Multiplier
R-4		HF Hamband Receiver
R-4A		HF Hamband Receiver
R-4B		HF Hamband Receiver
R-4C	1211	Amateur HF Receiver, 160-10 meters
		R-4C Spart Parts List
		PTO Main Bearing Adjustment
R7	1240	Amateur Band, Analog Readout Receiver (160-10 Meters)
		R7/TR7 Accessory Filter Installation
R7		Receiver Service Manual



Model	Part #	Description
R7A		Receiver
R8/R8E		Communications Receiver
R8/R8E		Receiver Service Manual
RCS-4	1518	Remote Coax Switch
		RCS-4 Spare Parts List
RP-500		Receiver Protector for Marine Products
RR-1		Marine Reserve Receiver - Early Version
RR-1		Marine Reserve Receiver - Later Version
RR-2		Communications Receiver
RV-3		Remote VFO for TR-3
RV-4		Remote VFO
RV-4C	1319	Remote VFO
RV-6		Remote VFO / Speaker for TR-6



Model	Part #	Description
RV-7	1338	Remote VFO for TR-7 Transceiver
RY-4	1225	Teletype Adapter for SPR-4
SC-2		2 Mtr. Receiveing Converter
SC-6		6 Mtr. Receiving Converter
SCC-1		Calibrator for SC-2 & SC-6
SCC-4	1223	VHF Crystal Calibrator
SL-300	7021	CW Filter, 300 Hz for TR-7 Transceiver
SL-500	7022	CW Filter, 500 Hz for TR-7 Transceiver
SL-1800	7023	SSB/RTTY Filter, 1.8 kHz for TR-7 Transceiver
SL-4000	7026	AM Filter, 4.0 kHz for TR-7 Transceiver
SL-6000	7024	AM Filter, 6.0 kHz for TR-7 Transceiver
SPR-4	1221	Solid State General Coverage Receiver
		Modification to SPR4 for 2.4 Kc SSB Filter on AM



Model	Part #	Description
		Crystals Price List & Crystal Frequencies
SP75		Speech Processor for TR7
		SP75 Addendum
		Modifications for SP75
SR-1		Receiver
SSR-1	8201	Synthesized General Coverage Receiver
SW-4		HF General Coverage Receiver
SW-4A		HF General Coverage Receiver.
T-4		HF Transmitter "RECITER"
		Tuning the T-4 Series to meet FCC purity requirements
		FR-4 Frequency Readout
T-4B		HF Transmitter
T-4X		HF Transmitter



Model	Part #	Description
		Transmitter Modifications for use with VHF Equipment
T-4		HF Transmitter "RECITER"
		DX Engineering LC-2-T4X Speech Processor
T-4XB		HF Transmitter
T-4		HF Transmitter "RECITER"
T-4XC		HF Hamband Transmitter
		T-4XC Manual Errata Sheet
		T-4XC Spare Parts List
TA-4		Transceive Adapter for SPR-4
TC-2		2 Mtr. Transverter
TC-6		6 Mtr. Transverter
TR-22		2 Mtr. Transceiver
TR-22C		2 Mtr. Transceiver



Model	Part #	Description
TR-22M		Marine VHF Transceiver
TR-3		HF Transceiver SSB/CW 80-10
		Tuning TR3 to meet FCC requirements
TR-33C	8333	2 Mtr. Transceiver
TR-4		HF Transceiver SSB/CW 80-10
		TR-3/TR-4 VHF Mod Kit
		Tuning TR4 to meet FCC purity requirements
		6JB6 Tube Replacements
		FR-4tr Frequency Readout
		FR-4tr Update
TR-44B		HF Transceiver
TR-4C		HF Transceiver
		TR-4C Instruction Manual Errata Sheet



Model	Part #	Description
TR-4Cw	1312	HF Transceiver
		RIT option
		Tuning TR4 to meet FCC requirements
TR5		H.F. Transceiver
TR-6		6 Mtr. SSB/CW Transceiver
TR-7	1337	HF Transceiver Operator Manual
		Phone Patch mod
		SP75 Mods
		VFO Mods
		RTM/RRM7 Replacement
		TR-7 Accessory Filter Installation
		NB-7 Noise Blanker Installation
		Modifications for 7077 mic on TR7



Model	Part #	Description
		How to convert a TR-7 to a TR-7A
TR-7	7037	Service Kit/Extender Board Set
TR-7	385-0004	HF Transceiver Service Manual
TR-7A		HF Transceiver
TR-72		2 Mtr. Transceiver
TR-M		SSB Radiotelephone
		TR-M Antenna Coupler
TV-100-LP		300 OHM 6 Meter Filter
TV-1000-LP		Low Pass Filter
TV-300-10HW		300 OHM 10 Meter Filter
TV-300-15HW		300 OHM 15 Meter Filter
TV-300-20HW		300 OHM 20 Meter Filter
TV-300-HP	1603	High Pass Filter, 300 ohm, twin lead



Model	Part #	Description
TV-300-LP		300 OHM Low Pass Filter
TV-300-FMT		FM Band Rejection
TV-3300-LP	1608	Low Pass Filter, 1Kw to 30 MHz, with sharp cutoff above 30 MHz
TV-42-LP	1605	Low Pass Filter, 100 watts continuous
TV-52-20LP		52 OHM Low Pass Filter
TV-52-40LP		1 KW Low Pass Filter
TV-5500-LP	1609	Low Pass Filter, 1 Kw to 30 MHz, 100 watts continuous on 6 meters
TV-72-HP		72 OHM 50 MHZ High Pass Filter
TV-75-HP	1610	High Pass Filter, 75 ohms, TV coax
TV-CB-LP		Citizen Band Low Pass
UHF-300-HP		High Pass Filter
UMK-3	1330	Remote Trunk Kit for UV-3 Transceiver
UV-3	1346	3-Band Transceiver System - Operator's Manual



Model	Part #	Description
UV-3		3-Band Transceiver System - Service Manual
W-4	1513	HF Wattmeter
		W-4 Parts List
W-4		HF Wattmeter
WH7	1514	HF Wattmeter/VSWR Bridge
WV-4	1515	VHF Wattmeter
		WV-4 Parts List
WV-4	1515	VHF Wattmeter